

UNION BALL VLVE ASSEMBLY

PRODUCT #	PRODUCT DESCRIPTION	OPERATION #	S.O.E. RANGE	REVISION LEVEL
UBV-000	UNION BALL VALVE	00-00000-000	From ____ To ____	00-0000-000

■ TCQ ● VERIFY ▲ WORK CONTENT

BILL OF MATERIALS:

ITEM #	PART #	DESCRIPTION	QTY
1	UBV-111	Body, Union Ball Valve	1
2	UBV-222	Handle, Union Ball Valve	1
3	UBV-333	O-ring, Union Ball Valve	2
4	UBV-444	Connector, Union Ball Valve	2
5	UBV-555	Union Nut, Union Ball Valve	2

PROCEDURE: UNION BALL VALVE ASSEMBLY

#	EXPLANATION:	
1	Insert O-rings (UBV-333, 2x) into the groove of the Body (UBV-111, 1x), on both ends	
2	On one end of the Body, align the Connector (UBV-444, 1x) to the Body and lock it with the Union Nut (UBV-555, 1x)	
3	Repeat Step 2 for the other end of the Body	
4	Mount the Handle (UBV-222, 1x) on top of the Body	

